



E3 CORE WALL ELEVATION
R110

E4 CORE WALL ELEVATION
R110

SIZE	EP	BAR M/RK	SND	V	TYP	CD	BENDING DIMENSIONS												
							A	B	C	D	E	F/R	G	H	J	K	O		
11		11A329				1	1-07	1-02						1-07		1-023			
6		6A319				2	3-10	3-10											
4		4A324				1	0-06	15-013						0-06					
4		4A325				1	0-06	9-05						0-06					
4		4A326				1	0-06	0-11						0-06					
4		4A327				1	0-06	9-093						0-06					
4		4A330				1	0-06	13-02						0-06					
4		4A331				1	0-06	10-093						0-06					
4		4A332				1	0-06	10-101						0-06					
4		4A333				1	0-06	13-013						0-06					

